


Inserting/Removing Zinc Air Battery



the battery door.

See Page 21 of the Operating Instructions.

Inserting/Removing Zinc Air Battery



Pull the battery door outward with your forefinger.


See Page 21 of the Operating Instructions.

Inserting/Removing Zinc Air Battery



See Page 21 of the Operating Instructions.

Inserting/Removing Zinc Air Battery



Place the new battery in the compartment with the plus (+) sign facing up. Your hearing aid uses a size 13 battery.

See Page 21 of the Operating Instructions.

Wearing the Hearing Instrument



Hold the main unit as shown in the image.

See Page 22 of the Operating Instructions.

Wearing the Hearing Instrument



Position the hearing instrument behind your ear.


See Page 22 of the Operating Instructions.

Wearing the Hearing Instrument



Insert the eartip in your ear. (After positioning the hearing instrument at the right place, turn on the hearing instrument.) See Pages 22 and 23 of the Operating Instructions.

Removing the Hearing Instrument



Hold the receiver unit and pull it straight out. (Make sure that the hearing instrument is powered off.)

See Page 25 of the Operating Instructions.